

EddyCus[®] inline ISO – Fiber Weight & Fiber Orientation

P_ISO_ 20



Inline Isotropy, Fiber Weight & Orientation Measurement of Discontinuous Carbon Fibers

SURAGUS' **new EddyCus inline ISO** enables inline assessment of uniformity and isotropy (alignment) of discontinuous carbon fiber materials. For recycled carbon fibers (rCF) especially, decisive properties on product quality and integrity such as **fiber orientation** or **degree of isotropy** and the **fiber distribution** or **weight uniformity** are measured. The EddyCus inline ISO determines these properties **non-destructively and without contact during production** and can be used to control the manufacturing of impregnated or dry airlayed, wetlayed, non-wovens and chopped fiber mats. When compared to alternative technologies such as Beta-Ray which can only measure fiber weight or optical systems which can only measure fiber angle, the EddyCus inline ISO incorporates a new sensor design with sensor focus and specialized algorithms enabling the simultaneous measurement of both fiber areal weight and bulk prevalent orientation for rCFRP or CF-SMC.

Based on **long-term proven** eddy current testing technology, the EddyCus inline ISO allows for inline testing of the **isotropic or anisotropic** character of **chopped**, **discontinuous**, **recycled mats or continuous carbon fiber non-wovens made for high performance application** in semi-structural parts.

SURAGUS GmbH Maria-Reiche-Straße 1 01109 Dresden Germany

+49 351/32 111 520 info@suragus.com

www.suragus.com www.carbon-fiber-testing.com www.suragus.com/FAQ www.suragus.com/CFinlineISO

Engineered and Made in Germany



EddyCus[®] inline ISO – Fiber Weight & Fiber Orientation





Fiber Areal Weight

Prevalent Fiber Orientation





Scaled Tensor

Anisotropy Strength

Measurement technology	Non-contact high frequency eddy current sensor		
Measurement area	20mm in diameter		
Required space	Small – approx. 300 mm in production line		
Sample rate	1 - 50 measurements per second 1 measurement/mm @ 5m/min production speed		
Interface	Process control with uplink to PLC or production control system via UDP or TCP/IP and API integration		
Value propositon	Degree of Isotropy (maximum orientation / min orientation Ratio MD/CD - machine direction to cross direction Fiber weight distribution [g/m ²] Fiber orientation in degree [°]		
Carbon fiber materials	CF non-woven, CF chopped, recyled CF, CF mats airlayed; sprayed discontinous CF with theromplastic or thermoset matrix		
Max. sample thickness	15 mm (larger on request)		
Web fluttering tolerance	1 mm		

Characterization & Application

Results

- Check local fiber orientation in cross section
- Identify high-/low density areas
- Non-destructive and no sample preparation

Application and Value

- Feedback of data into material flow simulation
- ► Evaluation of CF-SMC processing
- Distinction between GF / CF material
- Non-destructive material specification
- High quality short fiber product

SURAGUS Anisotrop	SURAGUS Anisotropy Test Application							Anisotropy	_ æ ⊃ ≪ Ready Ir
SUBARUSS	And Application mys and ap	Main Angle' 1936 25 1939 1946 1947 1946 1947 1946 1947 1946 1947 1946 1947 1946 1947 1947 1947 1947 1947 1947 1947 1947	Strengt 42 42 43 43 43 43 43 43 43 43 43 43	h SR Ang 0 an an an an an an an an an an an an an	2 SR 0% 124 126 126 120 120 120 124 124 126 126 126 126	 SR 420° SR 420°	 R 900 SR 900	Anisotropy 30 state 40 40 40 40 40 40 40 40 40 40	Paint State Paint Sta
	<i>∏</i> Settinos	The Amison	~ [the period	otropy Fil	e Calculati	00	Messages	Start Stop Oter